

UNIDRAULIC® Dual Vessel

Drill pipe should first be thoroughly cleaned at the place of installation. The outside diameter (OD) of drill pipe should be nominal; a smaller OD may result in slippage. Pins should be inserted from the top. Hand installation pliers are available. Weatherford's hydraulic installation tool is also available for installing slick and spiral-fluted drill pipe protectors. A standard removal tool can be applied to all protectors.

Accumulator

Vessel size - diameter and seam length	36" x 36"
Manway size	11" x 18"
Std. working pressure	225 psi
Optional working pressure	300 psi
Fluid capacity	4-1/3 bbls

Reservoir

Vessel size - diameter and seam length	60" x 120"
Manway size	14" x 18"
Std. working pressure	175 psi
Optional working pressure	240 psi
Fluid capacity	41 bbls

Standard Vessel Specifications

